

# **Mineraluxe Cleanse and Drain Instructions**

1. Maintain hot tub water temperature at 95 degrees or higher.
2. Remove the filter cartridge.
3. Add bottle of Cleanse and Drain to hot tub water.
4. Run high speed pump for at least 5 minutes, with diverter valves in the neutral position, jets on and air off. It will foam!
5. Maintain water temperature and allow the hot tub water to circulate through the plumbing.
6. For best results, run high speed pump two or three times over a 24 hour period.
7. Drain hot tub completely. Rinse and refill hot tub.